


ART-W bridge

Adjusting the action

To adjust the height of the entire bridge, use your fingers to turn the adjustment spinners located at the left and right ends of the bridge. (It is not possible to individually adjust the height of each string.)



Adjusting the intonation

To adjust the saddle position, loosen the strings and move the entire bridge.


※ Tune the guitar correctly before checking the intonation.



Memo

When loosening the strings, take care that the bridge does not fall over.

When replacing the strings, we recommend that you replace them one by one, since the bridge location will shift if you remove all strings at once.



EN

