

The background of the page is a dark gray. A white line-art outline of an acoustic guitar is centered vertically. The Ibanez logo is written in a white, elegant script font, overlapping the upper part of the guitar's body. Below the logo, the words "IBANEZ ACOUSTIC GUITAR" are written in a clean, white, sans-serif font. Two horizontal white lines are positioned above and below the preamp information text. The preamp information text is centered between these lines. At the bottom of the page, the website URL is written in a white, sans-serif font.

# *Ibanez*

IBANEZ ACOUSTIC GUITAR

---


**Preamp Information**

**AEQ200M**

---

[WWW.IBANEZACOUSTIC.COM](http://WWW.IBANEZACOUSTIC.COM)

# AEQ200M



AEQ200M

## Basic Controls

### VOLUME

Controls the overall gain of the Pre-Amp.

### TREBLE

Controls the boost/cut of the treble frequencies.

### BASS

Controls the boost/cut of the bass frequencies.



## Notes

Replace the batteries if you notice any of the following things.

- Decreased sound quality or volume
- The battery check LED is lit or blinking

To prevent the battery from being consumed needlessly, disconnect the plug from the output jack when you're not using the guitar.

- ※ Dispose of used batteries in accordance with local regulations.
- ※ Appearance and specifications are subject to change without notice.

