

A stylized white line drawing of an acoustic guitar is centered on a dark gray background. The drawing shows the neck with frets and tuning pegs at the top, the body with a circular soundhole, and the bridge with six strings at the bottom. The Ibanez logo is overlaid on the upper part of the guitar's body.

Ibanez


IBANEZ ACOUSTIC GUITAR

Preamp Information

AEQ200M

WWW.IBANEZACOUSTIC.COM

AEQ200M



AEQ200M

Basic Controls

VOLUME

Controls the overall gain of the Pre-Amp.

TREBLE

Controls the boost/cut of the treble frequencies.

BASS

Controls the boost/cut of the bass frequencies.



Notes

Replace the batteries if you notice any of the following things.

- Decreased sound quality or volume
- The battery check LED is lit or blinking

To prevent the battery from being consumed needlessly, disconnect the plug from the output jack when you're not using the guitar.

※ Dispose of used batteries in accordance with local regulations.

※ Appearance and specifications are subject to change without notice.

